

| CH | Instrument | Mic - Type | Insert | 48V | Remarks | Monitor Belegung M7 CL | |
|----|------------|------------|--------|-----|---------|------------------------|------------------------|
| 1 | Kick | D112 | | | | AUX1 | Wedge Center |
| 2 | Sn Top | Audix D2 | | | | AUX 2 | Wedge Keyboard |
| 3 | Sn Bot | Sennh 604 | | | | AUX 3 | Wedge Git |
| 4 | Rasta | Sennh 604 | | | | AUX 4 | Drum Sub |
| 5 | Hat | AKG 460 | | X | | AUX 5 | In Ear 1 left (Key) |
| 6 | Tom 1 | Audix D2 | | | | AUX 6 | In Ear 1 right (Key) |
| 7 | Tom 2 | Audix D2 | | | | AUX 7 | In Ear 2 mono (Ursula) |
| 8 | Tom 3 | Audix D3 | | | | AUX 8 | In Ear 3 mono (Gitti) |
| 9 | | | | | | AUX 9 | In Ear 4 mono (Jac) |
| 10 | O/H left | Shure SM81 | | X | | AUX 10 | In Ear 5 mono (Bass) |
| 11 | O/H right | Shure SM81 | | X | | AUX 11 | |
| 12 | Bass | DI | | X | | Aux 12 | Cue Wedge |
| 13 | Guit left | Sennh e906 | | X | | AUX 13 | Loom to Drums 1 |
| 14 | Guit right | Sennh e906 | | | | AUX 14 | Loom to Drums 2 |
| 15 | Akkordeon | AKG 535 | | X | | AUX 15 | Loom to Drums 3 |
| 16 | Leslie Bot | Sennh 421 | | | | AUX 16 | Loom to Drums 4 |
| 17 | Leslie Top | SM 57 | | | | | |
| 18 | Leslie Top | SM 57 | | | | | |
| 19 | Piano | DI | | X | | | |
| 20 | Moog | DI | | X | | | |
| 21 | Vs | DI | | X | | | |
| 22 | Vs | DI | | X | | | |
| 23 | Alesis | DI | | X | | | |
| 24 | Alesis | DI | | X | | | |
| 25 | Sampler | DI | | X | | | |
| 26 | Sampler | DI | | X | | | |
| 27 | Acc 1 | Radio | | X | | | |
| 28 | Acc 2 | DI | | X | | | |
| 29 | Ursula | SM 58 | | | VOX | | |
| 30 | Gitti | SM 58 | | | VOX | | |
| 31 | Jacqueline | SM 58 | | | VOX | | |
| 32 | Gü B3 | SM 58 | | | VOX | | |
| 33 | Gü Piano | SM 58 | | | VOX | | |
| 34 | Bucherl | SM 58 | | | VOX | | |
| 35 | Peter | SM 58 | | | VOX | | |
| 36 | WA | SM 58 | | | VOX | | |
| 37 | Spare | SM 58 | | | VOX | | |
| 38 | | | | | | | |
| 39 | | | | | | | |
| 40 | Andi | TB | (FOH) | | | | |